

TEST & TAG

TEST & TAG ELECTRICAL EQUIPMENT



The Occupational Safety and Health Act 1984 (OSH Act) requires electrical equipment at workplaces to be safe and not expose workers to hazards.

As prescribed by the Occupational Safety and Health Regulations 1996 (the OSH regulations), the person having control of a workplace or access to that workplace, i.e. employer, the self-employed person, main contractor, must ensure that all portable plug-in electrical equipment and residual current devices (RCDs) at the workplace are safe and appropriately inspected, tested and maintained by a competent person (The Occupational Safety and Health Regulations 1996 (the OSH regulations) 3.59 to 3.63, 4.37 and 4.38).

QEC offers Test & Tag services that will ensure your organisation is both safe and compliant with the OH&S Standards in Australia. We extend an inclusive electrical Test and Tag service solution that will fit in your budget and help you to develop a documented report while maintaining a safe work place.

All Electrical Test & Tag Services are completed in accordance with AS/ANZ 3760:2010 standard.

WHAT WE TEST



Visual Inspection



Insulation Resistance



Polarity




Microwave Leakage Safety Audits



Earth Continuity



Earth Leakage



RCD Safety Audits





Examples of Electrical items tested are:

- Phone, Tablets, Laptops, eftpos, Computers, Printers and other office equipment
- Extension Leads and Power Boards
- Kitchen appliances such as Microwaves
- In the workshop environment Power Tools, Battery Charges and Machinery

In addition to test and tag services, we are able to provide a range of convenient products to the customers at very competitive prices, such as **RCD Boxes**, **25 Metre Leads**, **Power Leads** for all electrical appliances.

At QEC, only competent technicians will undertake the testing of electrical equipment. Our talented technicians have acquired, through training, qualification or experience, or a combination of these, the knowledge and skills required to test electrical equipment competently.

Our technicians can recognise electrical hazards or potentially unsafe conditions and also know what to:

- look at;
- look for; and
- do.



RECOMMENDED EQUIPMENT TEST AND TAG SERVICE CYCLE GUIDE

Type of environment and/or equipment		Interval between inspection and tests								
		Equipment including Class I equipment, Class II	Residual current devices (RCDs)							
		equipment, cord sets, cord extension sets and EPODs	Push-button t	est – by user	Operating time and push-button test					
	(a)	(b)	Portable (c)	Fixed (d)	Portable (e)	Fixed (f)				
1	Factories, workshops, places of manufacture, assembly, maintenance or fabrication	6 months	Daily, or before every use, whichever is the longer	6 months	12 months	12 months				
2	Environment where the equipment or supply flexible cord is subject to flexing in normal use OR is open to abuse OR is in a hostile environment	12 months	3 months	6 months	12 months	12 months				
3	Environment where the equipment orsupply cord is NOT subject to flexing in normal use and is NOT open to abuse and is NOT in a hostile environment	5 years	3 months	6 months	2 years	2 years				
4	Residential type areas of: hotels, residential institutions, motels, boarding houses, halls, hostels accommodation houses, and the like	2 years	6 months	6 months	2 years	2 years				
5	Equipment used for commercial cleaning	6 months	Daily, or before every use, whichever is the longer	N/A	6 months	N/A				
6	Hire equipment: Inspection	Prior to hire	Including push-button test by hirer prior tohire		N/A	N/A				
	Test and tag	3 months	N	/A	3 months	12 months				
7	Repaired, serviced and second-hand equipment	After repair or service which	could affect electrical safety, or on reintroduction to service, refer to AS/NZS 576							

*As per AS/NZS 3760 standard :Table 4 and this page must be read in conjunction with AS/NZS 3760 as a whole and particularly 2.1.



SAMPLE TEST & TAG REPORT

CLIENT NAME

Annual Test and Tag 2020

	Description	User	Test Instrument	Date	Retest Period	Next Test	Result
OCATION :							
-	1984	40.00	These Traperties		1000	1790000	PV
-	198.0	10000	Course Inspection	11-000	1004	111000	PV
-	1000.0	100.00	Name Inspection	111110	1.000	111000	PV
-	1000.0	10110-007	these requiries	111110	1000	111002-000	PV
10100	1080	10110-007	Characterization in the second second	11110	1004	011000000	P 🗸
-	100010	10.00	from important	1000	1004	11100	PV
	1008.0	4614	Tradi Ingenitori	01-000	1004	177000	PV
	1986.0	10100-007	These important	-	1004	11000	PV
-	108.0	10.0	The Institute		1000	1100.000	PV
	1008-01	10.00	Name Angendan		1000	1100000	PV
-	1000.0	100.00	New Ingenities	11-100		11100	PV
-	1980.0	100.00	Number Organities		a second	11100	Pv
-	THE OWNER AND A	40.00	THE FEE	ON		110000	P 🗸
	The second se						
	and the second s		NPLE	a state of the			
	100.0	SAN	and the second				
-	1986.0	SAN			1.000	110000	P 🗸
-	1986.0 Televi	The second			1004	179825800 179825800	P 🗸 P 🗸
***	1982 1982			11-100 11-000 11-000	11040	1780380 1780380 1780380	P v P v P v
	1862 1862 1862				19649 19649 19649 19649	178080 178080 178080 178080	P ~ P ~ P ~ P ~
	1857 1852 1852 1852				19669 19669 19669 19669	178080 178080 178080 178080 178080	P v P v P v P v
	1862 1862 1862 1862 1862				19649 19649 19649 19649 19649 19649	178080 178080 178080 178080 178080	P
	182 182 182 182 182 182 182				19649 19649 19649 19649 19649 19649	178280 178280 178280 178280 178280 178280	P ~ P ~ P ~ P ~ P ~ P ~ P ~
	1862 1862 1862 1862 1862				19649 19649 19649 19649 19649 19649	278280 278280 278280 278280 278280 278280 278280 278280	P ~ P ~ P ~ P ~ P ~ P ~ P ~
	1857 1852 1853 1853 1853 1853 1853				1964 1968 1968 1968 1968 1968 1968 1968	178080 178080 178080 178080 178080 178080 178080	P ~ P ~ P ~ P ~ P ~ P ~ P ~ P ~
	1862 1862 1862 1862 1862 1862				19669 19669 19669 19669 19669 19669 19669	178080 178080 178080 178080 178080 178080 178080 178080	P > P > P > P > P > P > P > P > P > P >
	1857 1852 1853 1853 1853 1853 1853 1853				1968 1968 1968 1968 1968 1968 1968 1968	178080 178080 178080 178080 178080 178080 178080 178080 178080	P >> P >> P >> P >> P >> P >> P >> P >>
	1857 1852 1852 1852 1852 1852 1852				19669 19669 19669 19669 19669 19669 19669 19669	178080 178080 178080 178080 178080 178080 178080 178080	P V P V P V P V P V P V P V P V P V P V
	1857 1852 1852 1852 1852 1852 1852 1852				19669 19669 19669 19669 19669 19669 19669 19669	118080 118080 118080 118080 118080 118080 118080 118080 118080 118080	



PORTABLE APPLIANCE TESTER USED



Electrical Testers Products	Class I & Class II	Extension Leads	Leakage Current	250V Insulation	500V Insulation	>10AMP Operation	RCD Testing	Mains Supply Test	Power Measurement	3 Phase Compatible	Microwave Radiations
Wavecom TnP-500											
Seaward Primetest Elite											
DeltaPAT Complete											
Metrel Delta Pro Print Pack											
Seaward Primetest PRO Kit											
Seaward Elite Kit											
Wavecom WCM-5M Microwave Tester											

Please note: This is only a basic guide for testing equipment and currently used at the time of publication. We do not intend to mislead consumers in anyway. For full specifications, please refer to the Manufacturers documentation or call us on +61 404 606 860.





FAILED TEST TAGS

Used for the items that has failed a test and need to be with drawn from service.



NEW TO SERVICE TAGS

These tags are used for items that are new to service and require testing and tagging in the future.

ELECTRICAL TEST TAGS



RCD TEST TAGS

These tags used for the RCD test identifications.



HI VIS FAILED TAGS

Light duty tags used for large volume testing in low traffic areas.



HI VIS FAILED TAGS

High visibility tags ensure that any failed items are clearly identified as a 'Failed Item' to ensure the safety of others.

He ind sel

HEAVY DUTY TAGS Heavy duty tags used in both

indoor and outdoor has a self-laminating security flap to protect the printed information.



SURFACE MOUNT PASS TAGS

These Surface Mounted Tags are specially designed for items where the other standard tags are too large.



INDUSTRIAL STRENGTH TAGS

Toughest self adhesive tags used for high-risk and harsh environment.



MICROWAVE LEAKAGE LABELS

Surface amount tag used to record test result on microwave leakage.





TESTER CALIBRATION

At QEC all the Portable Appliance Tester calibrated yearly and is an essential process for us that regularly undertakes testing and tagging. Our PAT tester is maintained carefully to ensure it is working as it should.

Which is as per AS/NZS 3760 2010 Standards, Appendix A ref: A6 TEST EQUIPMENT."The equipment required to carry out the tests detailed in this Standard (AS/NZS 3760) should be subjected to routine verification at regular intervals to ensure it is working correctly and its accuracy is maintained."

OUR CALIBRATION PROCESS



REMINDER

and the supervisor collects the testers from technicians and tagged as due for calibration/Out



BOOK

Admin team arrange the booking with the the authorised calibration & testing authorised calibration & testing

SEND



CALIBRATE

Authorised calibration & testing centres undertakes calibration.



COLLECT Collect the testers from the authorised calibration & testing centres with the

calibration certificates



Update the calibration details on the register Admin team handover the calibrated and reset the reminder for the next due date for equipment to the supervisor for calibration



allocation.

ALLOCATE Supervisor allocates th



